

IC Packaging/Intro

- ICs are at the core of a modern digital system
- Many systems fit entirely on a single IC (SOC)
 - a single $(15\text{-mm})^2$ chip can hold several million gates (1997)
 - a simple 32-bit CPU can be realised in an area of 1mm^2
- Biggest limitation of a modern digital IC: Large reduction in signal count between on-chip wires and package pins. Typical IC
 - 10^4 wiring tracks on each of four metal layers
 - 10^3 signals can leave the chip (for cheaper packages: 40..200)
 - Chips are often “pad-limited”. Peripheral-bonded chips. Chip area increases as the square of the number of pads

IC Packaging/Intro

- Most ICs are bonded to small IC packages

Although it is possible to attach chips directly to boards. Method used extensively in low-cost consumer electronics. Placing chips in packages enables independent testing of packaged parts, and eases requirements on board pitch and P&P (pick-and-place) equipment.

- IC Packages

- inexpensive plastic packages: <200 pins



- packages with >1000 pins available
(e.g. Xilinx FF1704: 1704-ball flip-chip BGA)

- IC Packaging Materials

- Plastic, ceramic, laminates (fiberglass, epoxy resin), metal

IC Packaging/Categories


- IC package categories:
 - **PTH** (pin-through-hole)
Pins are inserted into through-holes in the circuit board and soldered in place from the opposite side of the board
 - » Sockets available
 - » Manual P&P possible
 - **SMT** (surface-mount-technology)
SMT packages have leads that are soldered directly to corresponding exposed metal lands on the surface of the circuit board
 - » Elimination of holes
 - » Ease of manufacturing (high-speed P&P)
 - » Components on both sides of the PCB
 - » Smaller dimensions
 - » Improved package parasitic components
 - » Increased circuit-board wiring density




SMT packages offer many benefits and are generally preferred.

IC Packaging/Materials

- IC packaging material: Plastic
 - die-bonding and wire-bonding the chip to a metal lead frame
 - encapsulation in injection-molded plastic
 - inexpensive but high thermal resistance
 - **Warning:** Plastic molds are hygroscopic
 - » Absorb moisture
Storage in low-humidity environment. Observation of factory floor-life
 - » Stored moisture can vapourise during rapid heating
can lead to hydrostatic pressure during reflow process. Consequences can be: Delamination within the package, and package cracking. Early device failure.




IC Packaging/Materials



- IC packaging materials: Ceramic
 - » consists of several layers of conductors separated by layers of ceramic (Al_2O_3 “Alumina”)
 - » chip placed in a cavity and bonded to the conductors
Note: no lead-frame
 - » metal lid soldered on to the package
 - » sealed against the environment
 - » ground layers and direct bypass capacitors possible within a ceramic package
 - » high permittivity of alumina ($\epsilon_r=10$)
Note: High permittivity leads to higher propagation delay!
 - » expensive


IC Packaging/Popular IC Packages



Plastic Dual-In-Line
(PDIP)
here: PDIP14




SC70
here: SC70-5




Small Outline
Integrated Circuit
(SOIC)
here: SO14

Plastic Lead Chip Carrier (PLCC)
here: PLCC28




Thin Shrink Small Outline
(TSSOP)
here: TSSOP14

Thin Quad Flat Package
(TQFP)
here: TQFP32




IC Packaging/Popular IC Packages




Small Outline Integrated Circuit (SOIC)

- Shown: SO14, but available from SO8..SO28
- Gull-wing leads
- Popular, cost effective, and widely available IC package for low-pin-count ICs
- Dimensions: 8.6mm x 3.9mm x 1.75mm
- Pin-to-pin: 1.27mm (50mil)




IC Packaging/Popular IC Packages



Thin Shrink Small Outline (TSSOP)

- Shown: TSSOP14, but available up to TSSOP64
- Popular, cost effective, and widely available IC package for low-profile applications
- Dimensions: 5.0mm x 4.4mm x 1.2mm
- Pin-to-pin: 0.65mm (25mil)



IC Packaging/Popular IC Packages



Ball Grid Arrays (BGA)

- Shown: BGA54
- Available pin count >1700
- Advanced IC package for high-density low-profile applications
- Chip-scale package (CSP)
- Dimensions: 8.0mm x 5.5mm x 1.4mm
- Pin-to-pin: 0.8mm
- Low lead inductance



Altera Ultra-Fine-Line BGA

- Pin-Count: 169
- Dimensions 11mm x 11mm
- Profile: 1.2mm




Challenges:

- Integrity of solder joints
- Solder joint inspection (X-ray)
- Availability of 2nd source
- Routing


IC Packaging/BGA Physical Construction

Physical construction of a BGA

- Shown: Type-II BGA (cavity-down design)
- Interconnect: multi-layer laminated construction
- Die bonded onto a metal heat slug
- Solder balls make connection to a PC board
- 50 μ m bond wires
- Copper conductor thickness 20 μ m
- Layer separation 150 μ m



IC Packaging/BGA Electrical Model



Complexity of a detailed package model! For critical applications many more details are required (e.g. bond wire resistance). Field solver (e.g. LINPAR)!

IC Packaging/Thermal Resistances

- Comparison of thermal resistances

Package	RthJC K/W	RthJA (still air) K/W	RthJA (0.5m/s) K/W	RthJA (2.0m/s) K/W
DIP16	19	48		
SOIC24	17	77		
PLCC44	10	33	31	27
PQFP44	15	48	46	42
BGA256	13	40	38	33


IC Packaging/Electronic Assembly (1981)



IBM PC 1981

- IC packaging:
DIL only!
- Processor: 8088
- Memory: 256kB

IC Packaging/Electronic Assembly (2000)



**Low-density
electronic
assembly
with various
IC packages**

- SO
- TSSOP
- QFP
- BGA

Measurement Techniques

- Primary measurement tool: Oscilloscope
Other lab tools: Logic Analyser, Gain-Phase Analyser, Spectrum Analyser...
- Visualisation of electrical signals in the time domain
 - Visualisation of voltages through voltage probes (standard)
 - Visualisation of currents through current probes and current amplifiers
- Advanced scopes: Visualisation of signals in the frequency domain (FFT)

Measurement Techniques/DSO



**High speed digital design:
Use a DSO with adequate bandwidth!**

Digital storage oscilloscopes allow to capture and view events that may only happen once. Note the DSO's relatively poor vertical characteristics.

Features of modern scopes

- Type: Digital Storage Oscilloscope (DSO)
- Channels: 2 (standard), 4 (better)
- Bandwidth: 100MHz ... >5GHz
- Sampling rate: 200MS/s ...
- Memory: 1kpts ... Mpts
- Advanced triggering
- Signal analysis
- 8/10/12 bit vertical resolution with 1% vertical precision
- Export of data (floppy disk)
- Remote control (GPIB)

Measurement Techniques/DSO

Primary Limitations of Scopes

- Vertical sensitivity. Most scopes offer a range of 10mV/div ... 10V/div
- Limited bandwidth

With respect to High-Speed Digital Design


- Vertical sensitivity of DSOs adequate for most digital situations
- Bandwidth!

What do bandwidth numbers mean?

Can you measure a 99MHz signal using a scope with a 100MHz bandwidth?

What exactly do you mean by “a 99MHz signal”. Sine wave? Bitrate?

Measurement Techniques/DSO/Bandwidth




Example Parameters

- Signal: $f_{cycle}=100\text{MHz}$ with $Tr/Tf=1\text{ns}$
- Top: Scope BW = 100MHz
- Bottom: Scope BW = 350MHz

Signal distortion:

Signal harmonics are attenuated and phase-shifted by different amounts.

remember that $f_{knee} \approx \frac{0.35}{Tr_{10\%-90\%}}$



Measurement Techniques/DSO/Probes




Scope probes establish a connection between the circuit under test (CUT) and the scope.

Mission of scope probes: “Extract minimal energy from the CUT and transfer it to a scope with maximum fidelity”.

Scopes can only measure what they can “see” at their input ports. Choosing proper probes is vital for your measurement system.

Measurement Techniques/DSO/Probes





Primary factor degrading the performance of scope probes when used in high-speed digital electronics:

- Inductance of the ground wire

Watch out:

Bandwidth specifications of scope probes do NOT include the ground wire !

Measurement Techniques/DSO/Probes




How does the inductance of the ground wire affect measurements?

- Estimation of the ground loop inductance of the scope probe...
- Estimation how the ground loop inductance affects the rise time...

Measurement Techniques/Loop inductances


Estimation of self inductance of circular and rectangular loops:



$$L_{circ} \approx 614 \frac{nH}{meter} \cdot x \cdot \left(\ln \left(\frac{8x}{d} \right) - 2 \right)$$

Note:

- valid for $x \gg d$
- small influence of wire diameter




$$L_{rect} \approx 400 \frac{nH}{meter} \cdot \left(x \cdot \ln \left(\frac{2y}{d} \right) + y \cdot \ln \left(\frac{2x}{d} \right) \right)$$

Note:

- valid for $x \gg d$ and $y \gg d$
- small influence of wire diameter

Measurement Techniques/Loop inductances



Example Parameters

- 500MHz passive probe
- Ground wire 25mm x 75mm x 0.5mm
- Probe capacitance 10pF



- Self inductance of ground wire loop is around 200nH (!)
- Self inductance and capacitance of the probe result in a signal rise time of 4.7ns
- The knee frequency of this signal is around 74MHz. The 500MHz probe has been degraded to a 74MHz probe by the ground wire.

The bandwidth of a passive probe can be substantially reduced by ground wires!

Measurement Techniques/Loop inductances

Therefore...

- Don't use ground wires for measuring high-speed digital signals
- Use special probe tips (bare probe tip with probe collar directly grounded to circuit board)
- In general: Minimise loop areas



Measurement Techniques/DSO Pitfalls

More scope probe pitfalls...

- Capacitive loading of CUT due to scope probe.

Example: A 10pF probe represents an impedance of 136Ω to a signal with $T_r=3\text{ns}$

- Pickup of EM fields
 - For minimum magnetic field pickup: minimise ground loop area
 - Electric field pickup: hardly ever a problem in digital electronics
 - Popular trick of designers: Use scope probe as an EM field sensor
- Noise pickup due to probe shield currents

Remember: Composite rise time of scope probe and scope...

$$T_{r_{\text{composite}}} = \sqrt{\sum_{i=1}^n T_{r_i}^2} = \sqrt{T_{\text{probe}}^2 + T_{\text{scope}}^2}$$

Transmission Lines/Overview

– Transmission Lines (TL)

- Shortcomings of ordinary point-to-point wiring
 - Distortion, Emi, Crosstalk
- Modelling and Partial Differential Equations
- Characteristic Impedance and Propagation Constant
- Popular Types
- Classification
- Infinite Length Uniform Transmission Lines
 - Lossless Transmission Lines
 - Lossy Transmission Lines

TL/Wires

- A few words about wires...
 - Wires are used in digital systems to
 - communicate signals from one place to another
 - distribute power, clocks, etc.
 - Wires dominate a modern digital system in terms of
 - speed (propagation delay)
 - power (driver, termination)
 - cost (use right cost model.... expensive mistakes!)
 - Wires may not be equipotential regions
 - Real wires have distributed parasitics (R, L, C)
 - If not handled properly these parasitics will
 - add delay, cause oscillations, degrade signal quality...

With proper engineering techniques, wires can be easily tamed...

TL/Wiring in Digital Systems

- Wiring Hierarchy in Digital Systems
 - chips (metal layer, poly)
 - carrier (bond wires)
 - circuit boards (PCB)
 - chassis (shared mechanical support for PCBs)
(connected through backplanes, motherboards, cables)
 - cabinet
- Physical characteristics of wires at each level determines
 - electrical properties
 - cost
 - maximum signal density
(non-uniform increase in wire density: IC 22%/year vs PCB 7%/year)

TL/Classification of Wires

Remember...

Effective length of rising edge


$$l_r = T_r \cdot v_p$$



•if $l < l_r/6$
⇒ System behaves
mostly in a lumped
fashion


•if $l > l_r/6$
⇒ System behaves
mostly in a distributed
fashion

TL/Wiring Problems




- Problems of ordinary point-to-point wiring (example: wire-wrap prototyping)
 - Signal distortion (due to lumped or distributed parasitic wire components)
 - Radiated and conducted noise (EMI). Emission and susceptibility.
 - Crosstalk (inductive, capacitive)
- Common reasons for problems:
 - Large loops: large inductances
 - Vicinity to ground or other circuits: Capacitances

TL/Approximations for Suspended Wire





Capacitance and Inductance (per unit length) of round wire suspended above ground plane (valid for $h > d$):



$$C_{wire\ pul} \approx 2\pi \cdot \epsilon_0 \cdot \left(\ln\left(\frac{4h}{d}\right) \right)^{-1} \approx 55.6 \frac{pF}{meter} \cdot \left(\ln\left(\frac{4h}{d}\right) \right)^{-1}$$

$$L_{wire\ pul} \approx \frac{\mu_0}{2\pi} \cdot \ln\left(\frac{4h}{d}\right) \approx 200 \frac{nH}{meter} \cdot \ln\left(\frac{4h}{d}\right) \quad (\text{assumed dielectric: vacuum/air})$$

TL/Approximations for Suspended Wire



Interestingly:

$$C_{wire\ pul} \cdot L_{wire\ pul} \approx const$$

Indicates that propagation delay and propagation velocity is approximately independent of h and d .

$$\frac{L_{wire\ pul}}{C_{wire\ pul}} \neq const$$

Indicates that the characteristic impedance is a function of h and d .

TL/Point-to-Point Wiring Example

Example Breadboarding of Prototypes:



- Wire-wrap prototype using AWG30 wire (diameter $250\mu\text{m}$)
- Average height above ground: 5mm
- Average wire length: 10cm.
- Resulting average self inductance: $L=88\text{nH}$



TL/Point-to-Point Wiring Example

Example (continued):

- Average self inductance: $L=88\text{nH}$
- Typical load capacitance $C=15\text{pF}$. TTL driver with 50Ω output impedance.
- $d=0.33$. Overshoot 34%



TL/Point-to-Point Wiring Example

Example (continued):

- If height above ground is reduced to $120\mu\text{m}$ (resembling a *transmission line on PCB*):
- $L=14\text{nH}$. $d=0.82$. Overshoot 1%.

